


TEENSY 4.0 TO 3.6 BREAKOUT WITH USB HOST



INSTALL D1 OR S2, BUT NOT BOTH
S2 CAN BE A SPDT SLIDE SWITCH
OR A 3-PIN MALE HEADER WITH A JUMPER

BLACKKETTER
USB HOST BOARD

3 CASTELLATED HOLES

1 MM PITCH
CASTELLATED HOLES